Ojo...

Ojo Customer Service

Contact us by phone at:

1-877-FOR-MY-OJO
(1-877-367-6965)

To learn more Ojo facts, visit us at:

www.motorola.com/ojo

FCC Information

This equipment complies with Parts 15 and 68 of the FCC rules and the requirements adopted by the Administrative Council for Terminal Attachments (ACTA).

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

Notification of Local Telephone Company

On the bottom of this equipment is a label that contains, among other information, a product identifier in the form US:AAAEQ##TXXXX. You must, upon request, provide this information to your telephone company.

The digits represented by ## in the product identifier indicate the Ringer Equivalence Number (REN) for this equipment. The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed five. To be certain of the number of devices you may connect to your line as determined by the REN, contact your local telephone company.

NOTE: This product may not be used on coin service equipment provided by the telephone company.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this cordless phone does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

Notice must be given to the telephone company upon permanent disconnection of your telephone from your line. The FCC requires that you connect your cordless telephone to the nationwide telephone network through a modular telephone jack (USOC RJ11C/RJ11W or RJ14C/RJ14W).

Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practical, notify you that temporary discontinuance of service may be required.

Where prior notice is not practical and the circumstances warrant such action, the telephone company may temporarily disconnect service immediately. In case of such temporary discontinuance, the telephone company must:

- Promptly notify you of such temporary discontinuance
- Afford you the opportunity to correct the situation
- Inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations

The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

Interference Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference with one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for the radio or television that is "receiving" the interference).
- Reorient or relocate and increase the separation between the telecommunications equipment and the receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How to Identify and Resolve Radio/TV Interference Problems."

The FCC requires this product to be serviced only by Motorola or its authorized service agents.

CAUTION/WARNING: Changes or modifications not expressly approved by Motorola could void not only the user's authority to operate the equipment, but also the limited warranty.

Hearing Aid Compatibility

This telephone system meets the FCC standards for hearing aid compatibility.

MOTOROLA

Ojo Quick Start Guide

real life in real time

HELLO

Copyright © 2005 Motorola, Inc.

Copyright © 2005 WorldGate Service, Inc.

All rights reserved. WorldGate and the Ojo logo are trademarks and/or service marks of WorldGate Service, Inc. Motorola and the stylized M logo are registered in the U.S. Patent Office. All other trademarked products mentioned in this document are the sole property of their respective owners. Patents are pending with respect to this product. Use of the product is subject to a license agreement.

No part of this publication may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation or adaptation) without written permission from Motorola, Inc.

Motorola and WorldGate Services reserve the right to revise this publication and to make changes in content from time to time without obligation on the part of Motorola and WorldGate Services to provide notification of such revision or change. Motorola and WorldGate Services provide this guide without warranty of any kind, either implied or expressed, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Motorola and WorldGate Services may make improvements or changes in the product(s) described in this manual at any time.

MOTOROLA

520659-001
04/05

MGBI

1 Getting Started

Confirm that you have:

- High-speed Internet service
- Related cable or DSL modem
- Compatible router

Choose a location:

- Locate Ojo near your modem, and in a well-lighted area. (See "Ojo Lighting Tips" in your User Guide for additional information on setting the best lighting conditions.)

OR

- Locate Ojo anywhere in your house using HomePlug™ technology. For more information about using HomePlug in your home network, visit www.homeplug.com.

2 Unpacking Your Ojo

Check that the box contains the items pictured. If any parts are missing, contact an Ojo Customer Service Representative:

1-877-FOR-MY-OJO

(1-877-367-6965)

3 Installing the Battery Pack

Battery Safety Instructions

Do not burn, disassemble, mutilate, or puncture the battery. The battery contains toxic materials that could be released, resulting in injury.

CAUTION: There is a risk of explosion if you replace the battery with an incorrect battery type. Use only the battery that came with your phone or an authorized replacement recommended by the manufacturer.

- Keep batteries out of the reach of children.
- Remove batteries if storing 30 days or more.
- Do not dispose of batteries in fire; this could result in an explosion.

The rechargeable battery for this product must be disposed of properly and may require recycling. Contact your local recycling center for proper disposal methods.

Battery Installation

1. Press down on the indentation on the battery door and slide downward to remove.
2. Insert the battery connector into the receptacle (with the red wire to the left).
3. Insert the battery into the battery compartment.
4. Replace the battery door.
5. Place the handset in the cradle to charge the battery.

Note: It takes approximately 12 hours to charge the battery pack for the first time. You can register or make calls before the handset is fully charged by leaving the handset in the cradle.

4 Connecting Your Ojo



1. Confirm that the modem is properly connected to the router.
2. Turn off the power to both the modem and the router.
3. Plug one end of the provided Ethernet cable into the "ROUTER/MODEM" port on the back of Ojo and the other into an open port on the router.
4. Plug one end of the telephone line into a phone jack and the other end into the "WALL" port on the back of Ojo.
5. Turn on the power to the modem. Wait one minute, and then turn on the power to the router.
6. Plug one end of the Ojo power cord into the Ojo power block, and plug the other end into an electrical outlet.
7. Plug the power plug into the "12V" port on the back of Ojo.
8. Ojo powers on, performs a series of self-tests, and displays a series of startup screens. After a few minutes, the "Please Call Customer Service" screen appears.

Note: The initial "Start-Up" screen will show an "Activation Failed" message. After you establish an account for your Ojo, the failed status will clear.



5 Activating Your Ojo Service

Before you can use Ojo, you must register and establish an Ojo account. Your Ojo account enables you to make and receive video calls with other Ojo users.

Have available:

- Your 12-digit Ojo Unit ID number (found on the Ojo Help screen, the bottom of your Ojo, and on the box)
- A major credit card to activate your Ojo

You must call from a phone that uses the same phone number that your Ojo will use.

To activate your Ojo contact an Ojo customer service representative**:**

1-877-FOR-MY-OJO (1-877-367-6965)

For additional Ojo facts visit our website:

www.motorola.com/ojo

6 Making a Call

Ojo allows you to make both video and conventional telephone calls. To use Ojo for video calls, the other party must have an Ojo phone.

1. Enter "1" plus the phone number.
2. Press TALK.
3. Press SELECT to transmit your video image.
4. Press END to hang up.